

*Turn on: Turn on TV first > Turn on BM-4000 (to keep HDMI image stable)


*Turn off: Press "Power" button on BM-4000's front panel

A. Install Best Media APP

- Visit our website: www.bestmediausa.com > BM-4000
- Choose compatible device and download
- *For iOS: Go to APP store > Search: "BestMedia"
- > choose "iPhone only" > see "Best Media" > Download & Install
- *iPhone & iPad app is the same app.
- *Make sure your BM-4000 and your iPad/Android are connected to the same WIFI Router in order to connect successfully.

For Recording: (refer to Manual page 31)

Required: BM-4000, Mixing Amplifier (Amplifer & Mixer), & BM Touch Monitor



*RCA (Record voice) - for recording your voice into BM-4000. Then you can output it into USB. Require Touch Monitor to use Recording function

B. Setup Method 1: Wifi Mode (page 18)

- 1. Press "System" > Enter Password: 888888 (default) choose "Basic Setting" > "Wifi Set -> Wlan Card" (Pg 5/5)
- Use L/R to select Wlan Card, Up/Down to select selection
- Use "Enter" to enter WIFi setting and edit setting
 *Viet Interface: Hê Thống Cơ Bản > Wifi Set > "Wifi Mode"
- 2. Press "Enter" and select your Wifi network > Input Wifi Password
- Use L/R to select ## on keyboard, select "连线" (next to "m") to confirm
- 3. It will connect to network, press "Return" to back to Wifi page
- 4. System will connect to WIFI network and assign an IP address (see pic)
- 3. Press "Return" to return to the singing page, it automatically saved.



C. Connect via QR code(pg 18)

- 1. Open "Best Media" App, tap on "Disconnect" icon (top left)
- 2. Press "Menu" on remote, QR code on the TV screen or tap on "Phone" icon (lower right) on Touch Monitor
- 3. Scan the QR code and app will connect with BM-4000
- *If setup method 1 (Wifi mode) do not work, try step D or method 2 (Step F)



QR on TV screen



QR on Touch Monitor



未連接 / Disconnect



已連接 / Connected

D. Connect via Room

- 1. Open "Best Media" App, tap on "Disconnect" icon (top left)
- 2. On the camera screen, tap "Search" icon (located at top right corner)
- 3. App will search for available KOD machine
- 4. When Room is found, tap on "Connect" icon next to Room # to connect



E. Update Song List

- On Best Media App, tap "Me" icon
 "Setting" > "Download"
 tap on "Download to synch song
 - > tap on "Download to synch song list from machine
- 2. After song list updated, you can start to search song



我 / Me /



設定 / Setting / Setting

Tôi



更新歌單 / Song List / Song List



(i)

About

F. Setup method 2: Router Mode (pg 19)

- 1. Press "System" > "Basic Setting" > "Wifi Set -> "Router" (Pg 5/5)
 - Use L/R to select option, Up/Down to select selection
 - *Viet Interface: Hệ Thống Cơ Ban > Wifi Set > "Router Mode"
- 2. You have to enter New IP address. (refer 8B step 2-3 pg 19)
 - Use "C" to delete number, "enter" to insert (.) dot
- 3. Press "Return" to return to the singing page, it automatically saved.
- 4. Open smartphone/ tablet setting > WIFI > tap on "BM4000_XXXXX"
 - if you see BM-4000_XXXX meaning the IP is assigned correctly.
- 5. See green check mark on "BM-4000 XXXX"
- 6. Open Best Media App, app will automatically connect with BM-4000



- *If you do not see BM-4000_XXXX, try below option:
- 1. scan QR code (step C)
- 2. search room (step D)
- 3. change last group of IP in BM-4000 system setting
- 4. use step B and copy IP address
- 5. restart BM-4000
- connect CAT5 cable from BM-4000 (LAN) to WIFI cable, refer to Manual step 8B pg 19 to change new IP address.



On Touch Monitor:

- To check if the machine get corrected IP address:
- Tap "Service" > look for the IP address as pic shown IP: IP address

Client: Wifi network connected

Language

G. Change Language Interface

Me

- 1. On machine: press "System" > "Basic Setting" > "Lanugage" (Manual page 13)
- 2. On touch monitor: tap "Language" (globe icon) on Home page
- 3. On Best Media App: "Me" > "Setting" > "Language"



設定 Setting Setting

